

Want Tor on a Router? For fun and profit? Well here we go!

Hardware

We need the following:

- Raspberry Pi (Modell B, REV1 or REV2) ~40€
- A case for our Pi ~10€
- Transcend Extreme-Speed SDHC 16GB SDCARD ~12€
- Micro-USB 5V 1500mA Power Supply ~4€
- LAN Cable ~1€
- TP-Link TL-WN722N Wireless adapter ~12€
- D-Link DUB-H4 USB HUB ~18€

Makes a total of ~97€ for a rady-to-go Tor Hotspot. (amazon prices!)

Setup

Prepare the SDCard with the latest version of Raspbian.

```
wget -O /tmp/raspbian.img http://downloads.raspberrypi.org/raspbian\_latest  
dd if=/tmp/raspbian.img of=/dev/<YOUR SDCARD> bs=4M
```



- Plug the SDcard into the Pi
- Connect it with the LAN cable to your router/switch
- Connect the Pi with an HDMI cable to a monitor
- Connect the USB Hub to the Pi.
- On the HUB, connect an USB Keyboard and the Wireless adapter.
- Connect the USB Hub and the Pi to their power supplies and fire it all up.

Config

When raspi-config opens, tell it to expand the filesystem to the full size of your SDcard.
Next, go and enable the SSH daemon. Now you can change the hostname to something like "TorRouter".

Switch to the root user!

```
sudo su
```

Install Hostapd (does the Hotspot/Access Point) stuff, the DHCP server and Tor.

```
apt-get update && apt-get install isc-dhcp-server tor
```

For our setup we must compile Hostapd by hand as our TP-Link TL-WN722N uses a driver that's not enabled by the default raspbian hostapd.

```
apt-get install libssl-dev libnl-dev
```

```
wget http://w1.fi/releases/hostapd-2.0.tar.gz
```

```
tar xzvf hostapd-2.0.tar.gz
```

```
cd hostapd-2.0/hostapd
```

```
cp defconfig .config
nano .config
Uncomment the following line
#CONFIG_DRIVER_NL80211=y
Compile it!
make
make install
Edit dhcpd.conf
nano /etc/dhcp/dhcpd.conf
Comment the following lines out
# option domain-name "example.org";
# option domain-name-servers ns1.example.org, ns2.example.org;
Uncomment the following line
# authoritative;
Now add the following block of lines to the config (at the end of the file)
subnet 192.168.42.0 netmask 255.255.255.0 {
range 192.168.42.10 192.168.42.50;
option broadcast-address 192.168.42.255;
option routers 192.168.42.1;
default-lease-time 600;
max-lease-time 7200;
option domain-name "local";
option domain-name-servers 8.8.8.8, 8.8.8.4;
}
Edit /etc/default/isc-dhcp-server
nano /etc/default/isc-dhcp-server
Change the INTERFACES value to this
INTERFACES=wlan0
Now open /etc/network/interfaces and edit it to the following lines
iface lo inet loopback
iface eth0 inet dhcp

allow-hotplug wlan0
#iface wlan0 inet manual
#wpa-roam /etc/wpa_supplicant/wpa_upplicant.conf
#iface default inet dhcp

iface wlan0 inet static
address 192.168.42.1 netmask 255.255.255.0
Enable wlan0
ifup wlan0
Now we create /etc/hostapd/hostapd.conf
nano /etc/hostapd/hostapd.conf
Fill it with the following lines
interface=wlan0
driver=nl80211
ssid=TorRouter
hw_mode=g
channel=6
macaddr_acl=0
auth_algs=1
```

```
ignore_broadcast_ssid=0
wpa=2
wpa_passphrase=YOURSECRETPASSWORDGOESHERE
wpa_key_mgmt=WPA-PSK
wpa_pairwise=TKIP
rsn_pairwise=CCMP
Enable DAEMON mode in hostapd.
nano /etc/default/hostapd
Edit it
DAEMON_CONF="/etc/hostapd/hostapd.conf"
Now we need to download some more firmware for the chipset on our TP-Link
wget -O /etc/driver/htc_9271.fw
http://wireless.kernel.org/download/htc\_fw/1.3/htc\_9271.fw
Go ahead and start the 2 services!
service hostapd start
service isc-dhcp-server start
Enable autostart
update-rc.d hostapd enable
update-rc.d isc-dhcp-server enable
```

From:
<https://wiki.c3l.lu/> - **Chaos Computer Club Lëtzebuerg**

Permanent link:
https://wiki.c3l.lu/doku.php?id=projects:tor_hostspot&rev=1383062351

Last update: **2015/07/15 21:54**

